



Frequency range B

XS Wireless In-Ear Monitoring System



Ergänzende Informationen
 Supplementary Information
 Informations supplémentaires
 Informazioni supplementari
 Información adicional
 Informações suplementares
 Aanvullende informatie
 Dodatkowe informacje
 Yderligere oplysninger

Ytterligere informasjon
 Turvallisuusohjeita
 Επιπλέον πληροφορίες
 Kullanım Kılavuzuna Ek
 Дополнение к инструкции
 使用说明书补充
 取扱説明書の増補
 사용 설명서에 대한 보충사항
 معلومات إضافية

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 01/22, 587452/A02

SENNHEISER

DE

Für die Übertragung steht Ihnen folgender Frequenzbereich zur Verfügung:

Frequenzbereich	Bandbreite	Anzahl Frequenzen
572 - 596 MHz	24 MHz	max. 961

Die Sender und Empfänger verfügen über jeweils 8 Kanalbänke, auf denen werksseitig Frequenz-Presets voreingestellt sind. Innerhalb einer Kanalbank sind die Frequenz-Presets untereinander intermodulationsfrei. Sie sind nicht veränderbar.

In der Kanalbank **U** können Sie in 25-kHz-Schritten Frequenzen frei einstellen und abspeichern. Diese sind unter Umständen nicht intermodulationsfrei.

Die Frequenz-Presets in den Kanalbänken **1 bis 8** sind in der Tabelle auf der folgenden Seite dargestellt.

Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen

In Ihrem Land gelten möglicherweise gesonderte Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen.

Informieren Sie sich vor der Inbetriebnahme des Produktes unter folgender Adresse:

www.sennheiser.com/frequency-information

EN

Transmitters and receivers are available in the following frequency range:

Frequency range	Bandwidth	Number of frequencies
572 - 596 MHz	24 MHz	max. 961

Transmitters and receivers have 8 frequency banks respectively. Each of the channels in the frequency banks has been factory-preset to a frequency. These frequency presets within one frequency bank are intermodulation-free. They cannot be changed.

The frequency bank **U** allows the user to store individual frequencies which are freely selectable in 25-kHz steps. It might be that these frequencies are not intermodulation free.

The table printed on the following page lists the frequency presets in the frequency banks **1 to 8**.

Conditions and restrictions for using frequencies

There may be special conditions and restrictions for using frequencies in your country.

Before putting the product into operation, find the information for your country at the following address:

www.sennheiser.com/frequency-information

Frequenzbereich B / Frequency range B: 572 - 596 MHz

US TV channel	CH 31 (572 - 578)	CH 32 (578 - 584)	CH 33 (584 - 590)	CH 34 (590-596)
EBU TV channel	CH 33 (566 - 574)	CH 34 (574 - 582)	CH 35 (582 - 590)	CH 36 (590-598)

Channel	Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8
1	572.200	578.200	584.200	590.200	574.200	582.200	590.200	572.200
2	572.800	578.800	584.800	590.800	574.800	582.800	590.800	577.000
3	573.700	579.700	585.700	591.700	575.700	583.700	591.700	580.300
4	574.900	580.900	586.900	592.900	576.900	584.900	592.900	585.400
5	576.700	583.300	588.700	594.700	578.700	586.700	594.700	589.000
6	579.100	572.200	572.200	572.200	581.100	589.100	572.200	591.400
7	582.700	574.000	574.600	574.600	584.400	572.900	574.600	593.200
8	587.800	588.700	577.900	577.900	589.200	576.200	577.900	594.400
9	591.100	591.700	592.300	582.100	592.800	593.900	582.100	595.300
10	595.900	595.000	573.550	572.950	572.250	572.200	572.950	595.900
11	578.050	577.150	578.650	576.550	588.450	574.800	576.550	572.950
12	593.950	590.950	594.550	584.950	595.050	590.100	584.950	590.050