



Frequency range K

XS Wireless In-Ear Monitoring System



Ergänzende Informationen
 Supplementary Information
 Informations supplémentaires
 Informazioni supplementari
 Información adicional
 Informações suplementares
 Aanvullende informatie
 Dodatkowe informacje
 Yderligere oplysninger

Ytterligere informasjon
 Turvallisuusohjeita
 Επιπλέον πληροφορίες
 Kullanım Kılavuzuna Ek
 Дополнение к инструкции
 使用说明书补充
 取扱説明書の増補
 사용 설명서에 대한 보충사항
 معلومات إضافية

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
 www.sennheiser.com

Publ. 01/22, 587455/A02

SENNHEISER

DE

Für die Übertragung steht Ihnen folgender Frequenzbereich zur Verfügung:

Frequenzbereich	Bandbreite	Anzahl Frequenzen
925.2 - 937.3 MHz	12.1 MHz	max. 485

Die Sender und Empfänger verfügen über jeweils 8 Kanalbänke, auf denen werksseitig Frequenz-Presets voreingestellt sind. Innerhalb einer Kanalbank sind die Frequenz-Presets untereinander intermodulationsfrei. Sie sind nicht veränderbar.

In der Kanalbank **U** können Sie in 25-kHz-Schritten Frequenzen frei einstellen und abspeichern. Diese sind unter Umständen nicht intermodulationsfrei.

Die Frequenz-Presets in den Kanalbänken **1 bis 8** sind in der Tabelle auf der folgenden Seite dargestellt.

Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen

In Ihrem Land gelten möglicherweise gesonderte Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen.

Informieren Sie sich vor der Inbetriebnahme des Produktes unter folgender Adresse:

www.sennheiser.com/frequency-information

EN

Transmitters and receivers are available in the following frequency range:

Frequency range	Bandwidth	Number of frequencies
925.2 - 937.3 MHz	12.1 MHz	max. 485

Transmitters and receivers have 8 frequency banks respectively. Each of the channels in the frequency banks has been factory-preset to a frequency. These frequency presets within one frequency bank are intermodulation-free. They cannot be changed.

The frequency bank **U** allows the user to store individual frequencies which are freely selectable in 25-kHz steps. It might be that these frequencies are not intermodulation free.

The table printed on the following page lists the frequency presets in the frequency banks **1 to 8**.

Conditions and restrictions for using frequencies

There may be special conditions and restrictions for using frequencies in your country.

Before putting the product into operation, find the information for your country at the following address:

www.sennheiser.com/frequency-information

Frequenzbereich K / Frequency range K: 925.2 - 937.3 MHz

Channel	Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8
1	937.200	937.300	925.250	925.200	932.150	925.200	925.250	925.300
2	936.600	936.700	925.850	925.800	931.550	928.200	927.650	928.300
3	935.700	935.800	926.750	926.700	930.650	929.400	929.450	929.500
4	933.900	934.000	927.950	928.500	929.450	931.800	930.650	931.900
5	931.800	931.900	929.750	930.600	927.650	933.900	931.550	934.000
6	929.400	929.500	932.150	933.000	925.250	935.700	932.150	935.800
7	928.200	928.300	935.450	934.200	937.250	936.600	937.250	936.700
8	925.200	925.300	933.150	937.200	926.250	937.200	926.250	937.300
9	925.900	926.000	936.850	932.200	934.550	925.900	934.550	926.000
10	930.200	930.300	934.850	936.500	935.750	930.200	935.750	930.300